

SONO/MAX25® SOUNDPROOF SUBFLOOR

Installation Sheet



1. FLOOR SUBSTRATE


To ensure optimal installation and warranty coverage, first make sure that the floor substrate (concrete slab) is level. The surface must not have any irregularities such as waves or depressions. Using a straightedge or a level, check that the subfloor (concrete) does not exceed: 3/16" over a length of 10', or 1/8" over a length of 6'. If it is necessary to fill certain low spots, be sure to use a cement-based leveling compound with a compressive strength of 3000 lb/sq. in. If recommended, install a 0.6 mm polyethylene sheet over the floor surface prior to installation.

2. INSTALLATION

During installation, always leave at least 1/2" of clearance between the SONO/MAX25 system and walls, ducts, columns, etc.

First row : Cut the panel in half lengthwise (5" x 48"), with the textured side facing up, and insert the profiled strip. The strip must extend at least 8" beyond the panel joint.

Subsequent rows : Stagger the panels in a stepped pattern.



IMPORTANT

Before unpacking the product, allow it to acclimate for 24 hours in the room where it will be installed, at a minimum temperature of 18°C (64°F). A relative humidity level between 40% and 55% is required.

SONO/MAX25®
SOUNDPROOF SUBFLOOR
sonomax25.com